Drawing 7557/2



Levels indicated: 1KHZ for all controls set to 0 or neutral.
Lamps in push buttons are not shown.